

Site Prep

Alpine Structures offers several of these site-prep options.
Ask your salesman for availability in your area.

SMALL STRUCTURES



1. Limestone base should be 12" larger than building on four sides.
2. Remove 3-4" of sod.
3. Fill back in with No. 8 or No. 57 limestone.
4. Make sure entire area of limestone is level.



8"x16" x 2" thick concrete patio blocks are placed underneath each skid a maximum of 6' on center.



4x4"s are placed crossways underneath building. 4x4" supported with solid concrete blocks on low side and dug into ground (as needed) on high side.

great for smaller sheds!

LARGE STRUCTURES



Pressure/treated posts with 2x8" stringers for sloped applications.



Pressure/treated posts 8' o.c. with 2x8" treated rim boards and 2x8" treated cap.



Block foundation with frost protected footer and concrete floor.