## Site Prep

## Alpine Structures offers several of these site-prep options.

Ask your salesman for availability in your area.



- Limestone base should be 12" larger than building on four sides.
- 2. Remove 3-4" of sod.
- 3. Fill back in with No. 8 or No. 57 limestone.
- 4. Make sure entire area of limestone is level.



8"x16" x 2" thick concrete patio blocks are placed underneath each skid a maximum of 6' on center.



4x4"s are placed crossways underneath building.
4x4" supported with solid concrete blocks on low side and dug into ground (as needed) on high side.



## LARGE STRUCTURES



Pressure/treated posts with 2x8" stringers for sloped applications.



Pressure/treated posts 8' o.c. with 2x8" treated rim boards and 2x8" treated cap.



Block foundation with frost protected footer and concrete floor.